

# REAR PULLEY ADJUSTMENT



Remove the quick pins from the plastic strap pulleys and secure the strap to the pulley by sliding the quick pin back through the pulley and through the pocket in the strap. Adjust the position of the strap pulley on the rear rolltube by loosening the set screws in the pulley. Once close, tighten the **4 set screws** and repeat for other side. The strap runs in-between the ribs on the hood.

Once both straps are connected, close the tarp by pressing the **CLOSE** direction on the switch. When the tarp is closed check alignment of the strap pulleys to see if one side is tighter than the other. If one side is tighter than the other, loosen the sets screws of the tight pulley and turn the pulley back so it has the same tension as the other strap. The set screws are 90 degrees from each other. Note: Once the straps are tensioned and the tarp roles open and closed properly, drill 3/16" holes at each set screw location. This will prevent the pullies from slipping on the roll tube.