
Air Guage Camera Door Installation Instructions



- Remove the original air box door by drilling the three pop rivets that mount the door to the hinge.
- Install the new Camera Door with the supplied rivets, by pop riveting the door to the hinge.
- ❖ Mount the camera inside of the Camera Door.
 - The mounting hardware for the camera is included with the camera and is not supplied with the Air Box Camera Door.
- Locate a 12vdc power source to wire the camera into the Air Gauge box.
 - Most air gauge boxes will have a source within the box, typically a light.
 - ➤ If the camera was purchased from Michel Industries, the White wire will be the negative (-) ground wire and the Black wire will be positive (+) wire. If it was not purchased from Michel Industries refer to the instructions that came with the camera.
- Once the camera is wired and working correctly, adjust the camera to see the air gauge.
 - > Tighten all hardware to ensure that it will not move.

Industries, Ltd.
P.O. Box 119
St. Gregor, Saskatchewan
SOK 3X0 Canada

Ph# (306)366-2184 or Fax# (306)366-2145